

# CEE-BEE® CLEANER A-883



## AIRCRAFT EXTERIOR SURFACE CLEANER

CEE-BEE® CLEANER A-883 is a highly concentrated non-solvent gel, specifically designed to clean aircraft exterior surfaces. Also effective for degreasing engine exteriors, prior to tear-down.

### BENEFITS

- Effective at penetrating and removing heavy greasy soils
- Clings to vertical and overhead surfaces
- Rinses off easily without streaking, even after drying on the surface
- Safe on high strength steel, aluminum, magnesium, titanium; and other common structural aircraft alloys, good quality paints and acrylic plastics
- Non-toxic
- Won't stain after dwell time Has a pleasant, non-offensive odour
- Environmentally friendly, surfactants biodegradable
- Non-flammable

### PHYSICAL PROPERTIES

Appearance	Liquid	Solubility	Water soluble	Flammability	Non-flammable
Colour	Blue	pH	9-10	Density	1 g/ml
Odor	Pleasant odour	Flash Point	N/A		

### AVAILABLE FORMATS



20L

20CB883P

208L

20CB883D

1000L

20CB883T

### APPROBATIONS

- EPA 796.3100: AEROBIC AQUATIC BIODEGRADATION
- MIL-PRF-87937D, TYPE III (QPL)

## USE PROCEDURES

### HEAVY GREASY SOILS:

Apply undiluted. Will cling to vertical and overhead surfaces for maximum cleaning action.

Moderate to heavy soils: Dilute 1 part cleaner with 2 to 10 parts water, by volume.

Light to moderate soils: Dilute 1 part cleaner with 10 to 20 parts water, by volume.

### CLEANING APPLICATION WITH WATER RINSE:

1. Apply cleaner with mop, brush, or non-atomizing spray. To avoid streaking, start application at the bottom of the surface and work upward.
2. Allow cleaner to dwell at least 5 minutes until soils are penetrated; then agitate surface with a brush or mop.
3. Rinse thoroughly with high pressure water, starting at the top and working downward. Concentrated cleaner solutions will require additional rinsing to avoid streaking and filming.

### APPLICATION WITHOUT WATER RINSE:

1. Wipe the surface with a rag or mop, saturated with cleaner solution to loosen the soils.
2. Remove loosened soils with clean, dry rags and/or mops, turning frequently to avoid redeposition of soils.

### SPRAY-ON CLEANING AND DEGREASING ENGINE EXTERIOR:

1. Mask all openings to the engine interior: the inlet, exhaust, fuel and oil lines left open, bleeders, breather tubes and open electrical connectors.
2. Spray, steam, or foam on CEE-BEE® A-883 Cleaner. Allow to dwell 10 to 20 minutes. 3. Flush with warm or hot water.

## LEGISLATION

- WHMIS Regulated

## SAFETY & HANDLING

- Refer to Safety Data Sheet (SDS) for additional information
- Dispose of container and its contents in compliance with all applicable regulations.
- Avoid contact with eyes and skin; may cause irritations. Rubber gloves and safety glasses or face shields, are recommended while applying. • In case of accidental contact, flush affected areas thoroughly with water. If irritation persists, seek medical attention. • Do not ingest.

Information and recommendations regarding this product are presented in good faith. However no guarantees are associated with the data presented in this document, and no such guarantees should be interpreted from the information and expected results presented. We do not assume any liability for damage, loss or injury, direct or indirect, related to the use of this product.

Revised: 07 2020

P.2